

PASSENGER OXYGEN MASK - REMOVAL/INSTALLATION

EFFECTIVITY: ACFT MODEL(S) EMB-135

1. General

- A. This section gives the procedures to remove/install the passenger oxygen-mask assembly.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
35-20-04-000-801-A	PASSENGER OXYGEN MASKS ASSEMBLY - REMOVAL	ACFT MODEL(S) EMB-135
35-20-04-400-801-A	PASSENGER OXYGEN MASKS ASSEMBLY - INSTALLATION	ACFT MODEL(S) EMB-135

TASK 35-20-04-000-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-135

2. PASSENGER OXYGEN MASKS ASSEMBLY - REMOVAL

A. General

(1) This task gives the procedure to remove the passenger oxygen mask assembly.

B. References

REFERENCE	DESIGNATION
AMM TASK 35-20-01-000-801-A/400	CHEMICAL OXYGEN GENERATOR - REMOVAL
AMM TASK 35-20-01-400-801-A/400	CHEMICAL OXYGEN GENERATOR - INSTALLATION

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Dispensing units installed in the right and left PSUs, lavatory, and flight attendant station

I. Preparation

SUBTASK 841-010-B

(1) Open the circuit breakers below:

- PASS OXY DEPLOY 1 (location tip: ESSENTIAL DC BUS 1/MISCELLANEOUS).
- PASS OXY DEPLOY 2 (location tip: ESSENTIAL DC BUS 2).

J. Removal (Figure 401) (Figure 402)

SUBTASK 020-011-B

WARNING: • DO NOT USE OIL AND OTHER PETROLEUM-BASE LUBRICANTS ON THE OXYGEN EQUIPMENT. THIS COULD CAUSE A DANGEROUS FIRE AND BAD INJURY TO PERSONS.

- KEEP ALL SOURCES OF IGNITION (HOT EXHAUST, SPARKS, FLAMES, SMOKING) AWAY FROM THE OXYGEN SERVICING AREA.

CAUTION: DO NOT CUT THE TUBING THAT SUPPLIES THE PASSENGER MASK ASSEMBLY. REPLACE THE PASSENGER OXYGEN-MASK ASSEMBLY. IF ITS SUPPLY TUBING WAS MADE SHORTER.

- (1) Get access to the passenger oxygen mask assembly (4) through the doors (3) of the oxygen dispensing units. Refer to Figure 401, DET. A.

- NOTE:** • On the chemical oxygen generator actuator end, there is a dot indicator. Expended generator - when the dot is black or not expended generator - when the dot is orange.
- The gaseous oxygen cylinder in a not-used condition, the green indicator cap and the pull pin being in place. If the indicator cap is missing from the safety plug, it shows that the cylinder can be empty and you must not use it. Discard the cylinder without the indicator cap on the safety plug.
 - If the generator is expended, remove it and install a new, not expended, generator ([AMM TASK 35-20-01-000-801-A/400](#) and [AMM TASK 35-20-01-400-801-A/400](#)).

- (a) Do the removal of the passenger oxygen-mask assembly as follows:

- 1 Tag and safety the oxygen generator (1) with safety pin (11). Refer to Figure 401, DET. D.

WARNING: ALWAYS BE CAREFUL NOT TO ACCIDENTALLY PULL THE LANYARDS OR PULL-PIN OF A GENERATOR NOT USED. THE REMOVAL OF THE PULL-PIN FROM THE OXYGEN GENERATOR WILL START THE FLOW OF OXYGEN. AND YOU CANNOT STOP IT UNTIL THE GENERATOR IS EMPTY. THE EXTERNAL SURFACE WILL BECOME SUFFICIENTLY HOT TO BURN YOU.

CAUTION: DO NOT PUSH OR PULL THE FITTING OF THE OXYGEN-GENERATOR OUTLET VALVE IF THE OUTLET VALVE IS NOT SAFELY HELD.

- 2 Disconnect the lanyards (6) from the facepiece lanyard ring (7). Refer to Figure 401, DET. C.
 - 3 Remove the passenger oxygen mask assembly (4) from the mask retainer (5). Refer to Figure 401, DET. A.
 - 4 Disconnect the supply tubing (2) from the oxygen generator (1). Refer to Figure 401, DET. E.

- 5 Remove the passenger oxygen-mask assembly (4).
- 6 Put a cover (9) on the generator outlet (10). Refer to Figure 401, DET. E.
- (2) (AIRCRAFT FOR 16 PASSENGERS, Figure 402) Remove the passenger oxygen-mask assembly (1) as follows:
- (a) Open the door (2) to get access to the passenger oxygen-mask assembly (3).

WARNING: ALWAYS BE CAREFUL NOT TO ACCIDENTALLY PULL THE LANYARDS OR PULL-PIN OF SHUTOFF VALVE. THE REMOVAL OF THE PULL-PIN FROM THE SHUTOFF VALVE WILL START THE FLOW OF OXYGEN.


- (b) Disconnect the lanyards (7) from the facepiece lanyard clip (6).
- (c) Remove from the manifold assembly (8) the supply tubing (5) that supplies the passenger oxygen-mask assembly (3).
- (d) NOTE: On the tubing that supplies the mask, there is an indicator dot, which shows:
- There is oxygen flow, when the dot is green; or
 - There is not oxygen flow, when the dot is orange.

Remove the passenger oxygen-mask assembly (3).

EFFECTIVITY: ACFT MODEL(S) EMB-135

Passenger Oxygen Mask Assembly - Removal/Installation

Figure 401




EM145AMM350298A.DGN

EFFECTIVITY: AIRCRAFT FOR 16 PASSENGERS

Passenger Oxygen Mask Assembly - Removal/Installation

Figure 402




145AMM350202.MCE

EFFECTIVITY: AIRCRAFT FOR 16 PASSENGERS

Folding of the Passenger Oxygen-Mask Assembly

Figure 403



145AMM350163.MCE

TASK 35-20-04-400-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-135

3. PASSENGER OXYGEN MASKS ASSEMBLY - INSTALLATION

A. General

(1) This task gives the procedure to install the passenger oxygen masks assembly.

B. References

REFERENCE	DESIGNATION
AMM TASK 35-20-04-000-801-A/400	-
AMM TASK 35-20-04-860-801-A/200	PASSENGER OXYGEN MASKS - STOWAGE

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Dispensing units installed in the right and left PSUs, lavatory, and flight attendant station

I. Preparation

SUBTASK 841-011-B

- (1) Make sure that the aircraft is in the same configuration as it was at the end of the removal task (AMM TASK 35-20-04-000-801-A/400).

J. Installation (Figure 401) (Figure 402) (Figure 403)

SUBTASK 420-011-B

- WARNING:**
- **DO NOT USE OIL AND OTHER PETROLEUM-BASE LUBRICANTS ON THE OXYGEN EQUIPMENT. THIS COULD CAUSE A DANGEROUS FIRE AND BAD INJURY TO PERSONS.**
 - **KEEP ALL SOURCES OF IGNITION (HOT EXHAUST, SPARKS, FLAMES, SMOKING) AWAY FROM THE OXYGEN SERVICING AREA.**

- CAUTION:**
- DO NOT CUT THE TUBING THAT SUPPLIES THE PASSENGER MASK ASSEMBLY. REPLACE THE PASSENGER OXYGEN-MASK ASSEMBLY. IF ITS SUPPLY TUBING WAS MADE SHORTER.
 - DO NOT PERMIT THE TUBING THAT SUPPLIES THE PASSENGER MASK ASSEMBLY OR THE OXYGEN GENERATOR LANYARDS TO WEDGE OR BECOME ENTANGLED ON ANYTHING IN THE UNIT. THEY MUST BE FREE TO FALL OUT OF THE UNIT AS NECESSARY.

- (1) Install the passenger oxygen mask assembly as follows: (Figure 401)
 - (a) Remove the cover (9) from the generator outlet (10). Refer to Figure 401, DET. E.
 - (b) Connect the supply tubing (2) to the oxygen generator (1). Refer to Figure 401, DET. E.

NOTE: Make sure that supply tubing has a minimum grip of 13 mm (0.5 in) with the generator outlet (10).

WARNING: ALWAYS BE CAREFUL NOT TO ACCIDENTALLY PULL THE LANYARDS OR PULL-PIN OF A GENERATOR NOT USED. THE REMOVAL OF THE PULL-PIN FROM THE OXYGEN GENERATOR WILL START THE FLOW OF OXYGEN. AND YOU CANNOT STOP IT UNTIL THE GENERATOR IS EMPTY. THE EXTERNAL SURFACE WILL BECOME SUFFICIENTLY HOT TO BURN YOU.

- (c) Connect the lanyard (6) on the facepiece lanyard ring (7). Refer to Figure 401, DET. C.
 - (d) Remove the safety pin (11) from the oxygen generator (1). Refer to Figure 401, DET. D.
 - (e) Do the mask stowage ([AMM TASK 35-20-04-860-801-A/200](#)).
- (2) (AIRCRAFT FOR 16 PASSENGERS, Figure 402) Install the passenger oxygen-mask assembly as follows:

- (a) Fold the passenger oxygen-mask assembly (3), refer to (Figure 403).

- 1 Fold the reservoir bag (8) into thirds.

NOTE: When correctly folded, the legend can be easily seen.

- 2 Continue to fold the reservoir bag (8). Then push it into the facepiece (9) of the passenger oxygen-mask assembly on the top of the elastic head band (10).

NOTE: When correctly folded, the mask part can be easily seen.

CAUTION: BE CAREFUL NOT TO KINK THE TUBE IN THE FACEPIECE.

- 3 Wind the tubing (6) that supplies the passenger mask assembly clockwise into the facepiece (9), on the top of the folded reservoir bag (8). An approximate 50.8 mm (2 inch) outer diameter coil gets the best result. The flow indicator (11) must be the last part of the supply tubing in of the facepiece (9).

- (b) Install the supply tubing (5) that supplies the passenger oxygen-mask assembly to the manifold assembly (8).

WARNING: ALWAYS BE CAREFUL NOT TO ACCIDENTALLY PULL THE LANYARDS OR PULL-PIN OF SHUTOFF VALVE. THE REMOVAL OF THE PULL-PIN FROM THE SHUTOFF VALVE WILL START THE FLOW OF OXYGEN.

- (c) Connect the lanyards (7) to the facepiece lanyard clip (6).
- (d) Put the passenger oxygen-mask assembly (3) in the oxygen module box (1).

WARNING: THE STREAMER MUST BE FREE TO FALL OUT WHEN THE OXYGEN MODULE DOOR OPENS.

- (e) Fold the streamer (4) and put it in the oxygen module box (1) correctly to cause it to unfold by itself when the oxygen module door (2) opens.
- (f) Close the oxygen module door (2).

K. Follow-on

SUBTASK 842-006-B

- (1) Close the circuit breakers below:
- PASS OXY DEPLOY 1 (location tip: ESSENTIAL DC BUS 1/MISCELLANEOUS).
 - PASS OXY DEPLOY 2 (location tip: ESSENTIAL DC BUS 2).