

## DME ANTENNA - REMOVAL/INSTALLATION

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to remove and install the DME antenna.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
34-51-02-000-801-A	DME ANTENNA - REMOVAL	ALL
34-51-02-400-801-A	DME ANTENNA - INSTALLATION	ALL

TASK 34-51-02-000-801-A

EFFECTIVITY: ALL

## 2. DME ANTENNA - REMOVAL

### A. General

(1) This procedure gives the instructions to remove the DME antenna.

### B. References

REFERENCE	DESIGNATION
AMM MPP 53-01-02/400	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
131		Area below the passenger cabin floor - LH
142		Area below the passenger cabin floor - RH

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Polyethylene spatula	To remove the sealant	AR

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Lower forward fuselage

### I. Preparation

SUBTASK 841-002-A

**WARNING: MAKE SURE THAT THE AIRCRAFT IS IN A SAFE CONDITION BEFORE YOU DO THE MAINTENANCE PROCEDURES. THIS IS TO PREVENT INJURY TO PERSONS AND/OR DAMAGE TO THE EQUIPMENT.**

(1) Make sure that the aircraft is safe for maintenance.

- (2) On the circuit breaker panel, open the DME 1 and DME 2 circuit breakers and attach a DO-NOT-CLOSE tag to them.
- (3) Remove the floor panel 231 BF to access the DME 1 antenna and/or remove the floor panel 242BF to access the DME2 antenna (AMM MPP 53-01-02/400) .

J. Removal

*SUBTASK 020-002-A*

- (1) (AIRCRAFT WITH ANTENNAS THAT DO NOT HAVE GEL CONDUCTIVE GASKET)  
To remove the DME antenna, do as follows: (Figure 401)

- (a) Disconnect the coaxial connector (1) from the DME antenna (2).

CAUTION: BE CAREFUL WHEN YOU USE THE POLYETHYLENE SPATULA TO BREAK THE ANTENNA SEAL. TOO MUCH FORCE CAN CAUSE DAMAGE TO THE AIRCRAFT SKIN, THE COAXIAL CABLE, OR THE ANTENNA.

- (b) Use a spatula to remove the sealant from around the fuselage skin hole and the DME antenna (2), on the inner surface of the fuselage skin hole.
    - (c) Use a spatula to remove the sealant from around the DME (2) antenna and aircraft skin
    - (d) Remove the sealant used as protection of the screws (3).
    - (e) Remove the screws (3).

CAUTION: BE CAREFUL WHEN YOU USE THE POLYETHYLENE SPATULA TO BREAK THE ANTENNA SEAL. TOO MUCH FORCE CAN CAUSE DAMAGE TO THE AIRCRAFT SKIN, THE COAXIAL CABLE, OR THE ANTENNA.

- (f) Use a spatula between the baseplate of the DME antenna (2) and the aircraft skin to make the separation.
      - (g) Carefully pull the DME antenna (2) away from the fuselage.
      - (h) Remove the DME antenna (2).

- (2) (AIRCRAFT WITH ANTENNAS THAT HAVE GEL CONDUCTIVE GASKET) To remove the DME antenna, do as follows: (Figure 402)

- (a) Disconnect the coaxial connector (1) from the DME antenna (2).

CAUTION: BE CAREFUL WHEN YOU USE THE POLYETHYLENE SPATULA TO BREAK THE ANTENNA SEAL. TOO MUCH FORCE CAN CAUSE DAMAGE TO THE AIRCRAFT SKIN, THE COAXIAL CABLE, OR THE ANTENNA.

- (b) Use a spatula to remove the sealant from around the fuselage skin hole and the DME antenna (2), on the inner surface of the fuselage skin hole.
    - (c) Use a spatula to remove the sealant from the contour of the DME antenna (2) and aircraft skin.

- (d) Remove the sealant used as a protection of the screws (3).
- (e) Remove the screws (3).


**CAUTION:** BE CAREFUL WHEN YOU USE THE POLYETHYLENE SPATULA TO BREAK THE ANTENNA SEAL. TOO MUCH FORCE CAN CAUSE DAMAGE TO THE AIRCRAFT SKIN, THE COAXIAL CABLE, OR THE ANTENNA.

- (f) Use a spatula between the baseplate of the DME antenna (2) and the aircraft skin to make the separation.
- (g) Carefully pull the DME antenna (2) away from the fuselage.
- (h) Remove the DME antenna (2).
- (i) Remove and discard the gel conductive gasket (4).
- (j) Use a spatula to remove the sealant from around the connector of the DME antenna (2).

EFFECTIVITY: AIRCRAFT WITH ANTENNAS THAT DO NOT HAVE GEL CONDUCTIVE GASKET

DME Antenna - Removal/Installation

Figure 401




EM145AMM340162C.DGN

EFFECTIVITY: AIRCRAFT WITH ANTENNAS THAT HAVE GEL CONDUCTIVE GASKET

DME Antenna - Removal/Installation

Figure 402



EM145AMM341014C.DGN

TASK 34-51-02-400-801-A  
EFFECTIVITY: ALL

### 3. DME ANTENNA - INSTALLATION

#### A. General

(1) This procedure gives the instructions to install the DME antenna.

#### B. References

REFERENCE	DESIGNATION
AMM MPP 53-01-02/400	-
<a href="#">AMM TASK 20-13-21-700-801-A/200</a>	ELECTRICAL BONDING TEST - STANDARD PROCEDURES
<a href="#">AMM TASK 20-13-21-910-801-A/200</a>	TYPES OF ELECTRICAL BONDING AND SURFACE PREPARATION - STANDARD PROCEDURES
<a href="#">AMM TASK 34-51-00-700-801-A/500</a>	DME SYSTEM OPERATIONAL TEST
<a href="#">AMM TASK 34-51-02-000-801-A/400</a>	DME ANTENNA - REMOVAL
CPM 51-21-06	-
IPC 34-51-02	DME ANTENNA
SRM 51-20-01	-

#### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
131		Area below the passenger cabin floor - LH
142		Area below the passenger cabin floor - RH

#### D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Torque wrench	To torque	

#### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Polyethylene spatula	To remove the sealant	AR
Commercially available	Clean dry cloth	To clean the antenna base	AR

F. Consumable Materials

<i>SPECIFICATION (BRAND)</i>	<i>DESCRIPTION</i>	<i>QTY</i>
ASTM-D-740	Methyl Ethyl Ketone (MEK)	AR
780(WHITE) (ASTM-C-920)	Type II Class A White Silicone, Sealant	AR
P/S870 B-2 (MIL-PRF-81733)	Type II CL B-2 Polysulfide Aerodynamic Sealant	AR
PR1422 B-2 (AMS-S-8802)	Type I CL B2 Polysulfide Sealant	AR
ECL-G-46/PC-233/TR109 (MEP 10-069)	High Solids Polyurethane White Paint	AR

G. Expendable Parts

<i>ITEM</i>	<i>IPC REFERENCE (VENDOR REFERENCE)</i>	<i>QTY</i>
Gel Conductive Gasket	IPC 34-51-02	2

H. Persons Recommended

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Lower forward fuselage

I. Installation

**SUBTASK 420-002-A**

- (1) Make sure that the aircraft is in the same configuration as it was at the end of the removal task ( [AMM TASK 34-51-02-000-801-A/400](#))
- (2) (AIRCRAFT WITH ANTENNAS THAT DO NOT HAVE GEL CONDUCTIVE GASKET)  
To install the DME antenna, do as follows: (Figure 401)

**WARNING: BE CAREFUL WHEN YOU USE THE METHYL ETHYL KETONE (MEK). PUT ON SAFETY GOGGLES, PROTECTIVE GLOVES AND CLOTHING. DO NOT BREATHE THE GAS. DO THE WORK IN AN AREA WHICH HAS A GOOD FLOW OF AIR. THE METHYL ETHYL KETONE (MEK) IS POISONOUS AND HIGHLY FLAMMABLE.**

- (a) With a clean cloth soaked in Methyl Ethyl Ketone (MEK), clean the antenna base surface.

**CAUTION: MAKE SURE THAT THE ELECTRICAL BONDING GIVES A GOOD ELECTRIC CONDUCTIVE PATH. IF NOT, DAMAGE TO THE AIRCRAFT AND TO THE EQUIPMENT CAN OCCUR.**

- (b) Do the bonding procedure, method 12, on the antenna installation surface on the aircraft skin ([AMM TASK 20-13-21-910-801-A/200](#))
- (c) Put the DME antenna (2) in its installation position.
- (d) Install the screws (3).
- (e) Use a torque wrench to torque the screws (3) to 2.8 N.m. (25 lb.in) in a crisscross pattern.



- (f) Do the bonding test between the connector of the DME antenna (2) and aircraft ground ([AMM TASK 20-13-21-700-801-A/200](#)).
  - (g) Apply aerodynamic sealant P/S870 B-2 around the contour of the DME antenna (2), on the skin (SRM 51-20-01).
  - (h) Apply sealant 780 (WHITE) on the screw heads until you fully fill the recesses on the antenna body (SRM 51-20-01).
  - (i) Apply sealant PR1422 B-2 around the fuselage skin hole and the DME antenna base, on the inner surface of the fuselage skin (SRM 51-20-01).
  - (j) Connect the coaxial connector (1) to the DME antenna (2).
- (3) (AIRCRAFT WITH ANTENNAS THAT HAVE GEL CONDUCTIVE GASKET) To install the DME antenna, do as follows: (Figure 402)

**WARNING: BE CAREFUL WHEN YOU USE THE METHYL ETHYL KETONE (MEK). PUT ON SAFETY GOGGLES, PROTECTIVE GLOVES AND CLOTHING. DO NOT BREATHE THE GAS. DO THE WORK IN AN AREA WHICH HAS A GOOD FLOW OF AIR. THE METHYL ETHYL KETONE (MEK) IS POISONOUS AND HIGHLY FLAMMABLE.**

- (a) With a clean cloth soaked in Methyl Ethyl Ketone (MEK), clean the antenna base surface.
- (b) Carefully remove the protective release film identified with "ANTENNA SIDE" from the gel conductive gasket (4).
- (c) Carefully align the gel conductive gasket (4) with the screw holes and connector, and install it to the base of the DME antenna (2).
- (d) Carefully remove the protective release film identified with "AIRCRAFT SIDE" from the gel conductive gasket (4).

**CAUTION: MAKE SURE THAT THE ELECTRICAL BONDING GIVES A GOOD ELECTRIC CONDUCTIVE PATH. IF NOT, DAMAGE TO THE AIRCRAFT AND TO THE EQUIPMENT CAN OCCUR.**

- (e) Do the bonding procedure, method 12, on the antenna installation surface on the aircraft skin ([AMM TASK 20-13-21-910-801-A/200](#))
- (f) Put the DME antenna (2) in its installation position.
- (g) Install the screws (3).
- (h) Use a torque wrench to torque the screws (3) to 2.8 N.m (25 lb.in) in a crisscross pattern.

**CAUTION: BE CAREFUL WHEN YOU USE THE POLYETHYLENE SPATULA TO BREAK THE ANTENNA SEAL. TOO MUCH FORCE CAN CAUSE DAMAGE TO THE AIRCRAFT SKIN, THE COAXIAL CABLE, OR THE ANTENNA.**

- (i) If necessary, with a spatula, remove the excess gel of the conductive gel gasket (4) from around the DME antenna (2) and from the aircraft skin.

- (j) Do the bonding test between the connector of the DME antenna (2) and aircraft ground ([AMM TASK 20-13-21-700-801-A/200](#)).
- (k) Apply aerodynamic sealant P/S870 B-2 around the contour of the DME antenna (2), on the skin (SRM 51-20-01).
- (l) Apply paint ECL-G-46/PC-233/TR109 on the screw heads (CPM 51-21-06).
- (m) Apply sealant 780 (WHITE) on the screw heads until you fully fill the recesses in the antenna body (SRM 51-20-01).
- (n) Apply sealant PR1422 B-2 around the fuselage skin hole and the DME antenna base, on the inner surface of the fuselage skin (SRM 51-20-01).
- (o) Connect the coaxial connector (1) to the DME antenna (2).

J. Follow-on

*SUBTASK 842-002-A*

- (1) Remove all tools, equipment and unwanted materials from the work area.
- (2) Install floor panel(s) (AMM MPP 53-01-02/400).
- (3) On the circuit breaker panel, close the DME 1 and DME 2 circuit breakers and remove the DO-NOT-CLOSE tag from them.
- (4) Do the DME System Operational Test ( [AMM TASK 34-51-00-700-801-A/500](#)).